


































CARTON 1 :

1	Bottom frame KCT A01	X1		10	Latch rubber steels, white CTA 81/A01	X4		19	Side plate KHT A05	X4		27	Inside door of roller shutter roof box KCT A17	X1	
2	Middle frame KHT A160	X1		11	3 inch universal wheel WHM 1s80	X4		20	Plastic door KHT A01	X4		28	Outer door of roller shutter roof box KCT A18	X1	
3	Upper frame with basket buckle KHT A76	X1		12	Plug of U-pipe KHT A18	X4		21	Pillar cover KHT A55	X4		29	Aluminum pole of roof box KHT A22	X2	
4	5 inch directional wheel KCT A33	X2		13	Wheel hole plug KHT A17	X4		22	Adjusting nut KHT A42	X4		30	M12 screw, 841mm KHT A03	X4	
5	5 inch universal wheel with seat KCT A02	X2		14	Double wheel pallet KHT A16	X2		23	Inner grid plate KHT A13	X2		31	Aluminum pipe, 864mm KHT A04	X4	
6	12*3 Round Rubber Pad KHT A172	X16		15	Kentucky mop holder CTA 112	X2		24	Bracket cover KHT A77	X2		32	Movable clip holder PH 4042/11	X5	
7	M6x35 hexagon screw M635/Ser	X16		16	Push handle KHT A15	X1		25	Side plate of roller shutter with lock KHT A118	X1		33	Polypropylene hook CTA 143GY	X1	
8	M6x1.5x16 flat gasket M61516/Wash	X16		17	Double buckle support frame KHT A39	X1		26	Side plate of roller shutter with lock KCT A29	X1					
9	M6 self-locking nut M6B/Nut	X16		18	Trash bag KHT A99	X1									

Sabco Australia Pty Ltd.

9-13 Link Way Laverton North Vic, Australia 3026.

Ultimate Janitor Cart

Assembly Guide & Component List

SABC-2019



sabco[®]
[PROFESSIONAL]

Sabco Australia Pty Ltd.
www.sabco.com.au

